



## **Installation Guide Model 83202 and 83212**

1. Be sure the vehicle is shut off.
2. Be sure the vehicle is outside to maximize GPS visibility.
3. Write down the Unit's ESN# located on the white label (highlighted) on the unit. You will be asked for this number when calling to activate unit.
4. Locate the diagnostic port in your vehicle. This port looks similar to a printer port on your home computer.
5. The port is generally located in one of the following locations nearest to the driver's side of the vehicle:
  - The kick panel
  - Below the steering wheel
  - In front of the center console
  - On the center console
6. Plug the CyntrX unit into the port.
7. No need to twist or force the device into place. Gently plug device in.
8. After device is secure, be sure it does not interfere with your driving or entering and exiting the vehicle. There are two zip ties included in the box to help secure unit if needed.
9. After this is complete, please call CyntrX at 866-312-3782 to activate unit and verify the location.